

Typical Power-Over-Ethernet Configuration using Electric Strikes.

